

## Care instructions and important notes

Please note the following information to enjoy your wind turbine for a long time.

1. If necessary, assemble your wind turbine according to the enclosed instructions.
2. **The wind turbine is not a child's toy!**  
Please place the wind turbine out of the reach of children. And make sure that children can swallow parts of the wind turbine.
3. Please make sure that the wind turbine can move freely in all directions.
4. Never grab or grasp the moving wings. **INJURY**
5. Storms, squalls or very strong winds can damage or tear the wind turbine loose. In such a case, please move the wind turbine to a place protected from the wind.
6. We recommend storing the wind turbine in a dry place protected from frost in autumn and winter to avoid damage.
7. Do not clean the turbine with a dry cloth. Please always clean with a damp cloth. You can use dish soap for this. Please do not use corrosive or overly harsh cleaning agents

Please follow these instructions so that you can enjoy your wind turbine for a long time.

You use the wind turbine at your own risk and responsibility.

We do not accept any liability for damage caused by our wind turbine or to our wind turbine.

